




# **MODEL M1111 MILLING MACHINE W/DOVETAIL COLUMN**



## **OWNER'S MANUAL**

**Phone: (360) 734-3482 • Online Technical Support: [tech-support@shopfox.biz](mailto:tech-support@shopfox.biz)**

**COPYRIGHT © MAY, 2007 BY WOODSTOCK INTERNATIONAL, INC. REVISED DECEMBER 2007.**

**WARNING: NO PORTION OF THIS MANUAL MAY BE REPRODUCED IN ANY SHAPE OR FORM WITHOUT**

**THE WRITTEN APPROVAL OF WOODSTOCK INTERNATIONAL, INC.**



## **WARNING!**

This manual provides critical safety instructions on the proper setup, operation, maintenance and service of this machine/equipment.

Failure to read, understand and follow the instructions given in this manual may result in serious personal injury, including amputation, electrocution or death.

The owner of this machine/equipment is solely responsible for its safe use. This responsibility includes but is not limited to proper installation in a safe environment, personnel training and usage authorization, proper inspection and maintenance, manual availability and comprehension, application of safety devices, blade/cutter integrity, and the usage of personal protective equipment.

The manufacturer will not be held liable for injury or property damage from negligence, improper training, machine modifications or misuse.



## **WARNING!**

Some dust created by power sanding, sawing, grinding, drilling, and other construction activities contains chemicals known to the State of California to cause cancer, birth defects or other reproductive harm. Some examples of these chemicals are:

- Lead from lead-based paints.
- Crystalline silica from bricks, cement and other masonry products.
- Arsenic and chromium from chemically-treated lumber.

Your risk from these exposures varies, depending on how often you do this type of work. To reduce your exposure to these chemicals: Work in a well ventilated area, and work with approved safety equipment, such as those dust masks that are specially designed to filter out microscopic particles.

# Contents

|   |    |                                  |    |
|---|----|----------------------------------|----|
| INTRODUCTION .....                          | 2  | Table Travel .....               | 15 |
| Woodstock Technical Support.....            | 2  | Headstock Travel.....            | 16 |
| Machine Specifications .....                | 3  | Drill Chuck .....                | 17 |
| Identification .....                        | 5  | R-8 Collets.....                 | 18 |
| SAFETY.....                                 | 6  | Control Panel .....              | 19 |
| Safety Instructions for Machinery .....     | 6  | Calculating Spindle RPM .....    | 20 |
| Additional Safety for Milling Machines..... | 8  | Milling/Drilling Mode .....      | 21 |
| ELECTRICAL .....                            | 9  | Tapping Mode .....               | 21 |
| 110V Operation .....                        | 9  | Accessories .....                | 22 |
| Extension Cords .....                       | 9  | MAINTENANCE .....                | 24 |
| Electrical Specifications .....             | 9  | Schedule .....                   | 24 |
| SETUP .....                                 | 10 | Lubrication .....                | 24 |
| Unpacking .....                             | 10 | SERVICE.....                     | 25 |
| Inventory .....                             | 10 | Troubleshooting .....            | 25 |
| Machine Placement .....                     | 11 | Troubleshooting .....            | 26 |
| Cleaning Machine.....                       | 11 | Gibs and Backlash.....           | 27 |
| Bench Mounting .....                        | 12 | Service Lubrication .....        | 29 |
| Test Run and Spindle Break-In .....         | 13 | Electrical Components .....      | 30 |
| OPERATIONS .....                            | 14 | Wiring Diagram .....             | 32 |
| General .....                               | 14 | PARTS .....                      | 33 |
| Spindle Height Control .....                | 15 | Column, Table, and Inverter..... | 33 |
|   |    | Headstock and Controls .....     | 35 |
|   |    | Label Placement .....            | 38 |





# INTRODUCTION

## Woodstock Technical Support

Your new **SHOP FOX®** Mill with Dovetail Column has been specially designed to provide many years of trouble-free service. Close attention to detail, ruggedly built parts and a rigid quality control program assure safe and reliable operation.

Woodstock International, Inc. is committed to customer satisfaction. Our intent with this manual is to include the basic information for safety, setup, operation, maintenance, and service of this product.

We stand behind our machines! In the event that questions arise about your machine, please contact Woodstock International Technical Support at (360) 734-3482 or send e-mail to: **[tech-support@shopfox.biz](mailto:tech-support@shopfox.biz)**. Our knowledgeable staff will help you troubleshoot problems and process warranty claims.

If you need the latest edition of this manual, you can download it from **<http://www.shopfox.biz>**.  
If you have comments about this manual, please contact us at:

**Woodstock International, Inc.  
Attn: Technical Documentation Manager  
P.O. Box 2309  
Bellingham, WA 98227  
Email: [manuals@woodstockint.com](mailto:manuals@woodstockint.com)**

# MACHINE SPECIFICATIONS



Phone #: (360) 734-3482 • Online Tech Support: tech-support@shopfox.biz • Web: www.shopfox.biz

## MODEL M1111 MILLING MACHINE WITH DOVETAIL COLUMN

### Motor:

Type ..... 220V Brushless DC Motor (BLDC)  
 Horsepower ..... 1HP  
 Amps ..... 12 Amp  
 Phase ..... Single  
 Speed ..... 3500 RPM  
 Cycle ..... 60 Hz  
 Power Transfer ..... Cogged Belt  
 Bearings ..... Sealed, Permanently Lubricated

### Product Dimensions:


Weight ..... 364 lbs.  
 Length/Width/Height ..... 27"L x 30"W x 33<sup>3</sup>/<sub>4</sub>"H  
 Foot Print (Length/Width) ..... 16" x 13"

### Shipping Dimensions:

Type ..... Wood Crate  
 Content ..... Machine  
 Weight ..... 437 lbs.  
 Length/Width/Height ..... 33"L x 32"W x 42"H

### Electrical:

Switch ..... Forward/Reverse  
 Switch Voltage ..... 110V  
 Cord Length ..... 7 ft.  
 Cord Gauge ..... 14 gauge  
 Recommended Circuit Size ..... 15 Amp  
 Plug ..... NEMA 5-15  
 Power Supply ..... 110V, Single-Phase  
 Power Inverter ..... 110V to 220V

Continued on next page 

**General:**

|                                       |   |
|---------------------------------------|---|
| Spindle Travel .....                  | 2 <sup>3</sup> / <sub>4</sub> "         |
| Drawbar .....                         | <sup>7</sup> / <sub>16</sub> " x 20 TPI |
| Spindle Taper .....                   | R8                                      |
| Swing .....                           | 18"                                     |
| Longitudinal Table Travel .....       | 15 <sup>7</sup> / <sub>8</sub> "        |
| Cross Table Travel .....              | 5 <sup>3</sup> / <sub>4</sub> "         |
| Head Travel .....                     | 14 <sup>7</sup> / <sub>8</sub> "        |
| Max. Distance Spindle To Column ..... | 8"                                      |
| Max. Distance Spindle To Table .....  | 14 <sup>3</sup> / <sub>4</sub> "        |
| Max. Drilling Capacity .....          | 1"                                      |
| Max. Tapping Capacity .....           | <sup>1</sup> / <sub>2</sub> "           |
| Max. End Mill Capacity .....          | 1"                                      |
| Max. Face Mill Capacity .....         | 2"                                      |
| Spindle Speed Range .....             | 100-1750 RPM, +/- 10%                   |
| Quill Diameter .....                  | 2.362"                                  |

**Table:**

|                           |                                   |
|---------------------------|-----------------------------------|
| Table Length .....        | 21 <sup>5</sup> / <sub>8</sub> "  |
| Table Width .....         | 6 <sup>1</sup> / <sub>4</sub> "   |
| Table Thickness .....     | 1 <sup>1</sup> / <sub>2</sub> "   |
| No. of T-Slots .....      | 3                                 |
| T-Slot Width .....        | 0.470"                            |
| T-Slot Height .....       | 0.750"                            |
| T-Slot Centers .....      | 1 <sup>11</sup> / <sub>16</sub> " |
| Stud Size .....           | <sup>3</sup> / <sub>8</sub> "     |
| Lead Screw Diameter ..... | <sup>5</sup> / <sub>8</sub> "     |
| Lead Screw TPI .....      | 12                                |
| Lead Screw Length .....   | 26"                               |

**Construction:**

|                                    |                          |
|------------------------------------|--------------------------|
| Spindle Housing Construction ..... | Cast Iron                |
| Table Construction .....           | Surface Ground Cast Iron |
| Head Construction .....            | Cast Iron                |
| Column Construction .....          | Surface Ground Cast Iron |
| Base Construction .....            | Cast Iron                |
| Paint .....                        | Epoxy                    |

**Features:**

3-16mm Drill Chuck with Key R-8/JT-6 Arbor  
 Leveling Feet  
 Digital RPM Readout  
 Digital Milling Depth Readout  
 Digital Tapping Controls and RPM Adjustment  
 Tapping Direction Quick-Shift Buttons on Quill Levers  
 Manual Micro Depth Adjustment  
 Dovetailed Table Ways  
 Dovetailed Column Ways

# Identification




Figure 1. M1111 Identification.

- A. Safety Cap and Drawbar
- B. Fine Feed Knob
- C. Headstock Tilt Scale
- D. Main Power Switch
- E. Fine Feed Lock Knob w/Assist Lever
- F. HHeadstock Lock Lever
- G. Precision Dovetailed Column
- H. Longitudinal (X-Axis) Handwheel
- I. Cast-Iron Base
- J. Vertical (Z-Axis) Handwheel
- K. Cross (Y-Axis) Handwheel
- L. Adjustable Foot
- M. Table Locks
- N. Longitudinal Scale
- O. Milling Table
- P. Quill Handle Tapping Button
- Q. Drill Chuck
- R. Spindle Lock Lever
- S. Chip Guard
- T. Digital Spindle Depth Unit and Readout
- U. Chip Guard Safety Kill Switch
- V. Emergency Stop Button
- W. Control Panel
- X. Digital Spindle RPM Readout

# SAFETY

## WARNING

### For Your Own Safety, Read Instruction Manual Before Operating this Machine

The purpose of safety symbols is to attract your attention to possible hazardous conditions. This manual uses a series of symbols and signal words which are intended to convey the level of importance of the safety messages. The progression of symbols is described below. Remember that safety messages by themselves do not eliminate danger and are not a substitute for proper accident prevention measures.



Indicates an imminently hazardous situation which, if not avoided, **WILL** result in death or serious injury.



Indicates a potentially hazardous situation which, if not avoided, **COULD** result in death or serious injury.



Indicates a potentially hazardous situation which, if not avoided, **MAY** result in minor or moderate injury. It may also be used to alert against unsafe practices.

## **NOTICE**

This symbol is used to alert the user to useful information about proper operation of the machine.

## WARNING

### Safety Instructions for Machinery


1. **READ THROUGH THE ENTIRE MANUAL BEFORE STARTING MACHINERY.** Machinery presents serious injury hazards to untrained users.
2. **ALWAYS USE ANSI APPROVED SAFETY GOGGLES WHEN OPERATING MACHINERY.** Everyday eyeglasses only have impact resistant lenses, they are **NOT** safety goggles.
3. **ALWAYS WEAR AN ANSI APPROVED RESPIRATOR WHEN OPERATING MACHINERY THAT PRODUCES DUST.** Wood dust is a carcinogen and can cause cancer and severe respiratory illnesses.
4. **ALWAYS USE HEARING PROTECTION WHEN OPERATING MACHINERY.** Machinery noise can cause permanent hearing damage.
5. **WEAR PROPER APPAREL.** DO NOT wear loose clothing, gloves, neckties, rings, or jewelry which may get caught in moving parts. Wear protective hair covering to contain long hair and wear non-slip footwear.
6. **NEVER OPERATE MACHINERY WHEN TIRED, OR UNDER THE INFLUENCE OF DRUGS OR ALCOHOL.** Be mentally alert at all times when running machinery.



7. **ONLY ALLOW TRAINED AND PROPERLY SUPERVISED PERSONNEL TO OPERATE MACHINERY.** Make sure operation instructions are safe and clearly understood.
8. **KEEP CHILDREN AND VISITORS AWAY.** Keep all children and visitors a safe distance from the work area.
9. **MAKE WORKSHOP CHILD PROOF.** Use padlocks, master switches, and remove start switch keys.
10. **NEVER LEAVE WHEN MACHINE IS RUNNING.** Turn power off and allow all moving parts to come to a complete stop before leaving machine unattended.
11. **DO NOT USE IN DANGEROUS ENVIRONMENTS.** DO NOT use machinery in damp, wet locations, or where any flammable or noxious fumes may exist.
12. **KEEP WORK AREA CLEAN AND WELL LIT.** Clutter and dark shadows may cause accidents.
13. **USE A GROUNDED EXTENSION CORD RATED FOR THE MACHINE AMPERAGE.** Undersized cords overheat and lose power. Replace extension cords if they become damaged. DO NOT use extension cords for 220V machinery.
14. **ALWAYS DISCONNECT FROM POWER SOURCE BEFORE SERVICING MACHINERY.** Make sure switch is in **OFF** position before reconnecting.
15. **MAINTAIN MACHINERY WITH CARE.** Keep blades sharp and clean for best and safest performance. Follow instructions for lubricating and changing accessories.
16. **MAKE SURE GUARDS ARE IN PLACE AND WORK CORRECTLY BEFORE USING MACHINERY.**
17. **REMOVE ADJUSTING KEYS AND WRENCHES.** Make a habit of checking for keys and adjusting wrenches before turning machinery **ON**.
18. **CHECK FOR DAMAGED PARTS BEFORE USING MACHINERY.** Check for binding and alignment of parts, broken parts, part mounting, loose bolts, and any other conditions that may affect machine operation. Repair or replace damaged parts.
19. **DO NOT FORCE MACHINERY.** Work at the speed for which the machine or accessory was designed.
20. **SECURE WORKPIECE.** Use clamps or a vise to hold the workpiece when practical. A secured workpiece protects your hands and frees both hands to operate the machine.
21. **DO NOT OVERREACH.** Keep proper footing and balance at all times.
22. **MANY MACHINES WILL EJECT THE WORKPIECE TOWARD THE OPERATOR.** Know and avoid conditions that cause the workpiece to "kickback."
23. **BE AWARE THAT CERTAIN DUST MAY BE HAZARDOUS** to the respiratory systems of people and animals, especially fine dust. Make sure you know the hazards associated with the type of dust you will be exposed to and always wear a respirator approved for that type of dust.

# **!WARNING** Additional Safety for Milling Machines

SAFETY



- 1. UNDERSTANDING CONTROLS.** Make sure you understand the use and operation of all controls.
- 2. SAFETY ACCESSORIES.** Always use the chip guard in addition to your safety goggles when milling to prevent bodily injury.
- 3. HOLDING WORK.** Before starting the machine, be certain the workpiece has been properly clamped to the table. **NEVER** hold the workpiece by hand when using the mill.
- 4. CHUCK KEY SAFETY.** Always remove your chuck key, drawbar wrench, and any service tools immediately after use.
- 5. SPINDLE SPEEDS.** Select the spindle speed that is appropriate for the type of work and material. Allow the mill to gain full speed before beginning a cut.
- 6. SPINDLE DIRECTION CHANGES.** Never reverse spindle direction when milling or boring.
- 7. BE ATTENTIVE.** **DO NOT** leave mill running unattended for any reason.
- 8. MACHINE CARE AND MAINTENANCE.** Never operate the mill with damaged or worn parts. Maintain your mill in proper working condition. Perform routine inspections and maintenance promptly. Put away adjustment tools after use.
- 9. DISCONNECT POWER.** Make sure the mill is turned **OFF**, disconnected from its power source, and all moving parts have come to a complete stop before starting any inspection, adjustment, or maintenance procedure.
- 10. AVOIDING ENTANGLEMENT.** Keep loose clothing articles such as sleeves, belts or jewelry items away from the mill spindle. Never wear gloves when operating the mill.
- 11. CUTTING TOOL INSPECTION.** Inspect drills and end mills for sharpness, chips, or cracks before each use. Replace dull, chipped, or cracked cutting tools immediately. Handle new cutting tools with care. Leading edges are very sharp and can cause lacerations.
- 12. EXPERIENCING DIFFICULTIES.** If at any time you are experiencing difficulties performing the intended operation, stop using the machine! Contact our Technical Support at (360) 734-3482.

# ELECTRICAL

## ! WARNING

The machine must be properly set up before it is safe to operate. **DO NOT** connect this machine to the power source until instructed to do so in the "Test Run" portion of this manual.

## 110V Operation

The Model M1111 is designed for a 110V power supply; however, the motor receives 220V current from the built-in 110V-to-220V power inverter. We recommend connecting this machine to a dedicated circuit with a verified ground, using the circuit size below as a minimum. Never replace a circuit breaker with one of higher amperage without consulting a qualified electrician to ensure compliance with wiring codes.

This machine must be grounded! The electrical cord supplied with this machine comes with a grounding pin. If your outlet does not accommodate a ground pin, have it replaced by a qualified electrician.

If you are unsure about the wiring codes in your area or you plan to connect your machine to a shared circuit, you may create a fire or circuit overload hazard—consult a qualified electrician to reduce this risk.


## Extension Cords

We do not recommend using an extension cord; however, if you have no alternative, use the following guidelines:


- Use a cord rated for Standard Service (S).
- Do not use an extension cord longer than 50 feet.
- Ensure that the cord has a ground wire and pin.
- Use the gauge size listed below as a minimum.

## Electrical Specifications

| Operating Voltage | Amp Draw | Min. Circuit Size | Plug/Receptacle | Extension Cord |
|-------------------|----------|-------------------|-----------------|----------------|
| 110V Operation    | 12 Amps  | 15A               | NEMA 5-15       | 14 Gauge       |



5-15 P



5-15 R

Figure 2. 5-15 plug and receptacle.

## ! WARNING



**DO NOT** work on your electrical system if you are unsure about electrical codes and wiring! Seek assistance from a qualified electrician. Ignoring this warning can cause electrocution, fire, or machine damage.

# SETUP

## Unpacking

This machine has been carefully packaged for safe transportation. If you notice the machine has been damaged during shipping, please contact your authorized Shop Fox dealer immediately.


## Inventory

The following is a description of the main components shipped with the Model M1111. Lay the components out to inventory them.

**Note:** If you can't find an item on this list, check the mounting location on the machine or examine the packaging materials carefully. Occasionally we pre-install certain components for safer shipping.

| Box Inventory (Figures 3 & 4)                  | Qty  |
|--|------|
| A. Assembled Mill/Drill.....                   | 1    |
| B. Drill Chuck and JT6 x R8 Arbor .....        | 1    |
| C. Oil Bottle .....                            | 1    |
| D. T-Nuts .....                                | 2    |
| E. Open-End Wrenches 8-10, 12-14, 17-19mm..... | 1 ea |
| F. Drawbar Hex Wrench .....                    | 1    |
| G. Spindle Spanner Wrench .....                | 1    |
| H. Chuck Key.....                              | 1    |
| I. Hex Wrench Set 3, 4, 5, and 6mm .....       | 1 ea |

### ! WARNING



Keep machine disconnected from power until instructed otherwise.




Figure 3. M1111 out of the crate.





Figure 4. Inventory.


## Machine Placement

- **Bench Load:** This machine distributes a heavy load in a small footprint. Some workbenches or tool tables may require additional bracing to support both machine and workpiece.
- **Working Clearances:** Consider existing and anticipated needs, size of material to be processed through the machine, and space for auxiliary stands, work tables or other machinery when establishing a location for your mill.
- **Lighting:** Lighting should be bright enough to eliminate shadow and prevent eye strain.
- **Electrical:** Electrical circuits must be dedicated or large enough to handle amperage requirements. Outlets must be located near each machine, so power or extension cords are clear of high-traffic areas. Follow local electrical codes for proper installation of new lighting, outlets, or circuits.



**! WARNING**

USE helpers or power lifting equipment to lift this mill. Otherwise, serious personal injury may occur.



**! CAUTION**

MAKE your shop “child safe.” Ensure that your workplace is inaccessible to youngsters by closing and locking all entrances when you are away. NEVER allow untrained visitors in your shop when assembling, adjusting or operating equipment.




## Cleaning Machine

The table and other unpainted parts of your machine type are coated with a waxy grease that protects them from corrosion during shipment. Clean this grease off with a solvent cleaner or citrus-based degreaser. DO NOT use chlorine-based solvents such as brake parts cleaner or acetone—if you happen to splash some onto a painted surface, you will ruin the finish.



**! WARNING**

NEVER use gasoline or other petroleum-based solvents to clean with. Most have low flash points, which make them extremely flammable. A risk of explosion and burning exists if these products are used. Serious personal injury may occur if this warning is ignored!

**! CAUTION**

ALWAYS work in well-ventilated areas far from possible ignition sources when using solvents to clean machinery. Many solvents are toxic when inhaled or ingested. Use care when disposing of waste rags and towels to be sure they DO NOT create fire or environmental hazards.

# Bench Mounting

Four leveling feet have been included with your mill. However, for greater safety and better performance, your mill should be bolted to a workbench to provide maximum rigidity and safety.

## Secured Mounting

To mount the mill to the workbench, do these steps:

1. Determine the best position for the mill on the workbench.
- Note:** For the best performance, make sure the cross feed and the longitudinal handwheels extend out beyond the edge of the table surface. This will allow unrestricted handwheel operation.
2. Mark your hole locations using the mounting holes in the base as a guide.
  3. Drill the holes needed in the workbench.
  4. Place a precision level on the mill table and shim the mill until it is level side-to-side and front-to-back.
  5. Using appropriate power lifting equipment, place the mill on the workbench.
  6. Bolt the mill base to the top of the workbench (Figure 6).

## Unsecured Mounting

To setup the mill for temporary mounting, do these steps:

1. Using appropriate power lifting equipment, tilt the mill and install the four feet into the base.
2. Place the mill on the workbench.
3. Place your precision level on the mill table.
4. Loosen the hex nut(s), as shown in Figure 7, and turn the feet until the mill is level side-to-side and front-to-back.
5. Retighten the hex nuts.




Figure 5. Minimum working clearances and mill mounting bolt pattern.




Figure 6. Example of a through mount setup.




Figure 7. Leveling the mill.



# Test Run and Spindle Break-In

The Model M1111 spindle speed can be set from 100-1750 RPM. You must follow the proper break-in procedures to ensure the spindle bearings break-in and seat before putting a load on the machine.

To test run and break-in the spindle bearings, do these steps:

1. Do all lubrication procedures highlighted in **Lubrication** in **MAINTENANCE** on **Page 24**.
2. Make sure there are no obstructions around or underneath the spindle.
3. Remove the drawbar if there is no arbor or collet in the spindle.
4. Make sure all switches are **OFF** and connect the mill to the power source.
5. Turn the main power switch **ON**, and push the **START** button on the control panel. The spindle will begin to turn at a low RPM.
6. Now push the **+** button until the mill reaches approximately 600 RPM, then let it run for a minimum of 10 minutes.
  - If you suspect the mill is not working correctly, shut the mill **OFF**, disconnect it from power, and use the **Troubleshooting** table on **Page 25** to correct the problem before proceeding further.
  - If the mill is running smoothly, proceed to **Step 7**.
7. Increase the speed to 1000 RPM and let it run for another ten minutes.
8. Increase the speed to 1750 RPM and let it run for another ten minutes.
9. Turn the mill **OFF**.
10. Set the spindle to rotate in the opposite direction, and let it run at 1750 RPM for another ten minutes.

## NOTICE

DO NOT leave the area while break-in procedure is under way. You must be ready to stop the machine if any problem occurs.

## NOTICE

Failure to follow start up and spindle break-in procedures will likely cause rapid deterioration of spindle and other related parts.



Figure 8. Control panel.

# OPERATIONS

## General

This machine will perform many types of operations that are beyond the scope of this manual. Many of these operations can be dangerous or deadly if performed incorrectly.

The instructions in this section are written with the understanding that the operator has the necessary knowledge and skills to operate this machine. **If at any time you are experiencing difficulties performing any operation, stop using the machine!**


If you are an inexperienced operator, we strongly recommend that you read books, trade articles, or seek training from an experienced mill operator before performing any unfamiliar operations. **Above all, your safety should come first!**

### WARNING



**READ** and understand this entire instruction manual before using this machine. Serious personal injury may occur if safety and operational information is not understood and followed. **DO NOT** risk your safety by not reading!

### WARNING



**DO NOT** investigate problems or adjust the machine while it is running. Wait until the machine is turned **OFF**, unplugged and all working parts have come to a complete stop before proceeding!

### WARNING



**Always** wear safety glasses when operating this machine. Failure to comply may result in serious personal injury.



# Spindle Height Control

Spindle height is changed by unlocking the quill lock and using the down feed handles or the fine feed knob (Figure 9). The digital spindle height readout indicates the spindle height.

To change the spindle position, do these steps:

1. Unlock the quill lock lever and loosen the fine feed lock knob.

**Note:** Use the comfort lever (Figure 9) for additional leverage to unlock the fine feed lock knob if the knob is too tight. Do not use the comfort lever to tighten the knob.

2. Pull down on the quill feed levers to lower or raise the spindle. Lock the quill lock to hold the spindle in a particular position if you choose.

**Note:** Milling with the quill fully extended, can cause tool chatter. For maximum spindle rigidity when milling, lower the headstock, keep the spindle retracted completely with the quill lock lever locked, and the fine feed lock knob tightened.




Figure 9. Spindle controls.




Figure 10. Table X and Y-axis controls.

## Table Travel (X-Axis and Y-Axis)

### Longitudinal Feed

The longitudinal feed, or X-axis is moved by the handwheel shown in Figure 10 at the end of the table. The handwheel will move the table in both directions side-to-side. One complete revolution of the handwheel moves the longitudinal feed 0.100". There is also a scale on the front of the table for use when a tight tolerance is not required. The longitudinal feed can be locked in position by a table lock located on the front of the table (see Figure 11).

### Cross Feed

The cross feed or Y-axis in Figure 10, is moved with the handwheel on the front of the table base. One complete revolution of the handwheel moves the cross slide 0.100". The cross feed can be locked into position by a table lock located on the right side of the cross slide underneath the table (see Figure 11).




Figure 11. Table locks and scales.

# Headstock Travel (Z-Axis and Rotation)

Headstock height is adjustable in the vertical Z-axis to accept large workpieces. For unique milling operations, the headstock can be tilted right or left between 0° and 90°. Your mill has a dovetailed slide that allows you to reposition the headstock and change tooling without losing your alignment with a hole or milling path.

To raise or lower the headstock, do these steps:

1. Unlock the headstock slide lock lever shown in **Figure 12**.
2. Turn the Z-axis handwheel shown in **Figure 13** to raise or lower the headstock, then lock the headstock slide lock lever.

**Note:** Milling with the quill fully extended, can cause tool chatter. For maximum spindle rigidity when milling, lower the headstock, keep the spindle retracted completely with the quill lock lever locked, and the fine feed lock knob tightened.

To tilt the headstock to the left or right, do these steps:

1. DISCONNECT THE MILL FROM POWER!
2. Using a 17mm wrench, loosen both headstock tilt lock nuts (**Figure 14**).
3. Insert a 6mm hex wrench into the index pin release port (**Figure 14**), and turn the hex wrench clockwise to disengage the spring-loaded index pin from the headstock.
4. While watching the tilt scale, rotate the headstock to the required angle, and retighten the tilt lock nuts to hold the headstock in place.

**Note:** The index pin is spring loaded and serves only as a quick way to return the headstock close to zero. It is not intended to be an absolute zero degree stop. No other index holes exist at other angles in the headstock.




Figure 12. Headstock slide controls.




Figure 13. Z-axis control.





Figure 14. Headstock tilt controls.

# Drill Chuck


To remove the chuck and arbor from the spindle, do these steps:

1. DISCONNECT THE MILL FROM POWER!
2. Remove the drawbar safety cap (**Figure 16**).
3. Lock the quill in place with the quill lock.
4. Insert the pin spanner (**Figure 15**) into the two holes at the bottom of the spindle and hold the spindle.
5. Using the 17mm wrench, loosen the drawbar one turn only. DO NOT remove it. DO NOT completely unscrew the drawbar before striking it with the hammer, or you will damage the threads on the drawbar and the arbor.
6. Tap the top of the drawbar with the hammer. This will unseat the taper of the arbor from the spindle (see **Figure 16**).
7. Hold one hand under the chuck and finish loosening the drawbar by hand until it falls out of the spindle.

**Note:** The chuck is attached to the arbor using a JT6 taper. This attachment is considered to be semi-permanent. There should be no need to remove the chuck from the arbor. Inspect the chuck from time to time to make sure it is still tight on the arbor. If it is loose, use a dead-blow or other soft headed hammer to re-seat the taper.



**Figure 15.** Spindle holes.



**Figure 16.** Tapping on the drawbar.

To install the drill chuck and arbor, do these steps:

1. DISCONNECT THE MILL FROM POWER!
2. Insert the chuck arbor into the spindle so it engages the alignment pin inside of the spindle and makes contact with the drawbar threads.
3. While supporting the chuck with one hand, thread the drawbar into the arbor until the arbor seated up into the spindle taper.
4. Snug the drawbar with the drawbar hex wrench.

**Note:** Do not overtighten the drawbar. Overtightening makes arbor removal difficult and will damage the arbor and threads.

5. Install the drawbar safety cap (**Figure 16**).

## R-8 Collets



Your Model M1111 features an R-8 spindle taper, which gives the freedom to use standard R-8 collets.

To install the R-8 collet, do these steps:

1. DISCONNECT THE MILL FROM POWER!
2. Unscrew the drawbar cap.
3. Carefully clean the surface of the collet and spindle taper. Ensure that they are free of debris and are lightly oiled.
4. Insert the cutting tool into the collet, then insert the collet up into the spindle taper.
5. Rotate the collet so it engages the alignment pin inside of the spindle, then slide the collet upward until it makes contact with the drawbar threads.
6. While supporting the tool in the collet with one hand, thread the drawbar into the collet until the collet draws up into the spindle taper.
7. Snug the drawbar with the A 17MM wrench in your opposite hand.

**Note:** Do not overtighten the drawbar. Overtightening makes collet removal difficult and will damage the drawbar threads, collet, and the spindle taper. Keep in mind that the taper keeps the collet and tool in place. The drawbar simply aids in seating the taper.

To remove the collet, do these steps:

1. DISCONNECT THE MILL FROM POWER!
2. Tighten the headstock lock.
3. Protect the table surface with a piece of cardboard or hold the cutter/tool with a shop towel to prevent it from falling out of the collet.
4. Using the drawbar hex wrench, loosen the drawbar but DO NOT remove it.
5. Using the brass hammer, tap the drawbar to unseat the taper.
6. Unscrew the rest of the drawbar by hand and remove the collet.

**Note:** When not in use, always remove collets and cutting tools from the spindle taper. Oxidation may cause the collet to seize and make it hard to remove later.



# Control Panel

It is vital that you become familiar with the power controls before operating the Model M1111 (see **Figure 17**).

- A. **Spindle RPM Display:** Shows spindle RPM with an accuracy of +/- 10%.
- B. **Spindle Rotation Mode:** Shows the direction the spindle is turning.
- C. **Spindle Mode:** Shows STOP when the spindle is stopped. When spindle is rotating, the "STOP" indication disappears.
- D. **Spindle START Button:** Press START, and the spindle will rotate at 200 RPM in the milling/drilling mode, and the spindle rotation buttons on the control panel are enabled. The Green LED tapping lamp will not glow, and the spindle rotation buttons on the ends of the rack handles are disabled.
- E. **SPEED Buttons:** Press to select a milling/drilling or tapping RPM. In the milling/drilling mode the range is between 200 and 1750 RPM. In the tapping mode, the range is between 100 and 500 RPM.
- F. **Spindle Rotation Buttons:** Press these buttons to change spindle rotation direction for milling/drilling operations. Spindle direction can be changed at any RPM without stopping the spindle first.
- G. **Spindle STOP Button:** Stops spindle rotation. If you press the START button, the spindle speed will return to the last spindle RPM setting.
- H. **Tapping Button:** Switches the mill into tapping mode only when the motor is running. When in tapping mode, the LED tapping lamp glows and the RPM automatically drops to approximately 500 RPM. The spindle rotation buttons on the ends of the rack handles are also enabled and the spindle rotation buttons on the control panel are disabled.
- I. **Green LED Lamp:** Glows when the machine is in the tapping mode, and does not glow in the milling/drilling mode.
- J. **Emergency Stop Button:** Stops the mill. Rotate the button clockwise until it pops back out to reset it.
- K. **Green Main Power Lamp:** Glows when the main power switch is turned to the **ON** position.
- L. **Zero Button:** Zeros the digital spindle scale.
- M. **Spindle Height Digital Display:** Shows height of spindle.
- N. **mm/in Button:** Toggles units of measure between metric and inch conventions.
- O. **Digital Spindle Scale ON/OFF Button:** Turns the digital spindle scale **ON** or **OFF**.




Figure 17. Control panel.

# Calculating Spindle RPM

Closely follow the proper cutting speed and proper feed to reduce undue strain on all moving parts and increase operator safety.

Prior to milling, determine the RPM needed to cut your workpiece, then set the RPM on the machine.

**To determine the needed RPM, do these steps:**

1. Use the table in **Figure 18** to determine the cutting speed required for the material of your workpiece.
2. Measure the diameter of your cutting tool in inches.
3. Use the following formula to determine the needed RPM for your operation:

$$(\text{Cutting Speed} \times 4) / \text{Tool Diameter} = \text{RPM}$$

| Cutting Speeds for High Speed Steel (HSS)<br>Cutting Tools   |                     |
|--|---------------------|
| Workpiece Material   | Cutting Speed (sfm) |
| Aluminum & alloys  | 300                 |
| Brass & Bronze   | 150                 |
| Copper   | 100                 |
| Cast Iron, soft  | 80                  |
| Cast Iron, hard  | 50                  |
| Mild Steel   | 90                  |
| Cast Steel   | 80                  |
| Alloy Steel, hard  | 40                  |
| Tool Steel   | 50                  |
| Stainless Steel  | 60                  |
| Titanium   | 50                  |
| Plastics   | 300-800             |
| Wood   | 300-500             |
| <b>Note:</b> For carbide cutting tools, double the cutting speed. These values are a guideline only. Refer to the <i>MACHINERY'S HANDBOOK</i> for more detailed information. |                     |

**Figure 18.** Cutting speed table for HSS cutting tools.

## Milling/Drilling Mode

This mill is designed to use most end mills, drill bits, and face cutters that are 2" in diameter or less. The milling table has a coolant trough with drain for an optional cutting fluid system.

### **WARNING**

Failure to follow RPM and Feed Rate Guidelines may threaten operator safety from ejected parts or broken tools.

To mill a workpiece, do these steps:

1. Refer to **Control Panel** on **Page 19**, and learn the how to use the machine controls.
2. Zero the spindle height scale and select units of measure.
3. Clamp the workpiece to the milling table, and adjust the headstock to the needed height, depth of cut, and milling path.

**Remember:** Milling with the quill fully extended can cause tool chatter. For maximum spindle rigidity, keep the spindle retracted into the headstock as far as possible with the quill lock lever locked and the fine feed lock knob tightened.

4. Refer to **Calculating Spindle RPM** on **Page 20** to find the best spindle RPM.
5. Put on your safety goggles, turn the power switch **ON**, and press the START button.
6. Push the FORWARD or REVERSE button to select the appropriate cutting direction for the type of cutter that you are using.
7. Press the SPEED button to select the appropriate milling speed for the diameter of cutter and type of material to be cut.
8. Use the X-axis or Y-axis handwheels to feed the workpiece into the cutter slowly. If you are only milling in one direction, lock the unused table slide in place. Refer to **Table Travel** on **Page 15** for lock lever location.

## Tapping Mode

This mill is designed to change spindle direction without stopping the spindle first. The wayed column allows for drill and tap changes and headstock repositioning without losing the tool registration. Using the mill in the tapping mode takes some level of skill, so make sure to practice using this feature. Avoid cutting threads in blind holes where the tap may bottom out and break before you can push the REVERSE button.

### **WARNING**

Failure to follow RPM and Feed Rate Guidelines may threaten operator safety from ejected parts or broken tools.

To drill and thread a hole, do these steps:

1. Refer to **Control Panel** on **Page 19**, and learn how to use the machine controls.
2. Zero the spindle height scale and select units of measure, and calculate your maximum tapping depth without bottoming-out the tap.
3. Clamp the workpiece to the milling table, and adjust the headstock to the needed height for drilling and tapping.
4. Put on your safety goggles, turn the power switch **ON**, and press the START button.
5. Drill your hole with the appropriate speed and drill bit size for the tap. For large holes you may have to drill a pilot hole.
6. Install the tap, and apply tapping fluid or oil when needed.
7. Push START, then the TAPPING button, and then the SPEED button. The safest tapping speed is 100 RPM.
8. Begin threading, but without disengaging the threads, frequently push the FORWARD and REVERSE buttons on the downfeed handles to cut and back-out the tap to eject the chips from the hole and prevent thread galling.

## Accessories

The following M1111 milling machine accessories may be available through your local Woodstock International Inc. Dealer. If you do not have a dealer in your area, these products are also available through online dealers. Please call or e-mail Woodstock International Inc. Customer Service to get a current listing of dealers at: 1-800-545-8420 or at [sales@woodstockint.com](mailto:sales@woodstockint.com).

**The Shop Fox D3694—Variable Speed Power Feed Kit** For those repetitive power-fed milling operations, this fantastic 110V power feed retrofit kit offers consistent speed control in both left and right directions for your Model M1111 milling machine. Let it do your work!




Figure 19. Variable speed power feed kit.

**The Shop Fox D3695—Horizontal Milling Table** Take advantage of the Model M1111 mill 90° tilting head-stock feature. Install this lifted cast-iron horizontal milling table for the correct clearance when making those side-milling operations.




Figure 20. Horizontal milling worktable.

**The Shop Fox D3693—Worktable with Angle** Enjoy having an economical way to support your workpiece at an array of angles. This high-quality tilting worktable is quick and easy to setup and use.




Figure 21. Worktable with angle.



## Accessories

### The Shop Fox M1078—6" Precision Rotary Table

Has the following great features: 4 T-slots for  $\frac{3}{8}$ " studs,  $4^\circ$  per rotation of the hand wheel, 10 minute vernier resolution, whole degree marks on table, coolant trough and the worm gear can be easily disengaged for quick setting angles, an MT#2 center hole, and weighs approximately 49 lbs.




Figure 22. 6" Precision rotary table.

### The Shop Fox M1079—Precision R-8 Collets

These R-8 Collets are precision ground to very close tolerances and will maximize your milling rigidity. Sizes include:  $\frac{1}{8}$ ",  $\frac{3}{16}$ ",  $\frac{1}{4}$ ",  $\frac{5}{16}$ ",  $\frac{3}{8}$ ",  $\frac{7}{16}$ ",  $\frac{1}{2}$ ",  $\frac{9}{16}$ ",  $\frac{5}{8}$ ",  $\frac{11}{16}$ ",  $\frac{3}{4}$ " and  $\frac{7}{8}$ ."



Figure 23. Precision R-8 collets.

### The Shop Fox M1080—52-pc. Clamping Kit

The kit includes: Case hardened blocks, bolts, nuts and hold-downs. Each Clamping Kit includes: 24 studs, 6 step block pairs, 6 T-nuts, 6 flange nuts, 4 coupling nuts and 6 end hold-downs. We offer the two most popular sizes:  $\frac{3}{8}$ " and  $\frac{1}{2}$ ". Racks can be bolted to the wall or on the side of a machine for easy access.




Figure 24. Clamping kit.

### The Shop Fox M1091—18-pc. R-8 Boring Head Set

The set includes: 2" boring head, 9 carbide tipped boring bars with  $\frac{1}{2}$ " shanks. 2 facing tools with  $\frac{3}{16}$ " square HSS cutting tools. Dial graduated in 0.001", 0.050" per revolution/0.025" actual motion. R-8 shank with  $\frac{7}{8}$ "-20 mounting threads. Stand included.





Figure 25. R-8 boring head set.

# MAINTENANCE



## Schedule

For optimum performance from your machine, follow this maintenance schedule and refer to any specific instructions given in this section.

### Daily Check:

- Mill is disconnected from power when not in use.
- Loose mounting bolts.
- Mill is clean and lubricated.
- Worn or damaged wires.
- Any other unsafe condition.

### Monthly Check:

- Gibs are adjusted properly.

### Annual or Biannual Check:

- Lubricate headstock lead screw and gears.

## Lubrication

Regular lubrication will ensure your mill performs at its highest potential. Place two to three drops of a general machine oil directly on the ways of the cross slide and saddle. An oil bottle has been provided for this purpose. Nine ball oilers (**Figures 26-28**) should be lubricated daily with several drops of oil.

Protect the unpainted cast iron surfaces with regular applications of light machine oil, and periodically clean and lubricate all lead screws with white lithium grease.




Figure 26. Headstock ball oiler locations.




Figure 27. Table and base ball oiler locations.





Figure 28. Table ball oiler location.

# SERVICE

## Troubleshooting




This section covers the most common problems and corrections with this type of machine. **WARNING! DO NOT** make any adjustments until power is disconnected and moving parts have come to a complete stop!

### General Operation

| PROBLEM  | POSSIBLE CAUSE   | CORRECTIVE ACTION   |
|--|--|---|
| Motor will not start.                                  | <ol style="list-style-type: none"> <li>Control system delay operating.</li> <li>Shop power supply is at fault.</li> <li>Chip guard switch at fault (<b>Figure 37</b>).</li> <li>Blown inverter fuse (<b>Figure 34</b>).</li> <li>Blown power supply fuse (<b>Figure 35</b>).</li> <li>Emergency stop button is pressed.</li> <li>Main power switch at fault (<b>Figure 35</b>).</li> <li>Shorted capacitor (<b>Figure 34</b>).</li> <li>Shorted inverter (<b>Figure 34</b>).</li> <li>Loose connections, open wiring.</li> <li>Motor is at fault.</li> </ol> | <ol style="list-style-type: none"> <li>Push and hold the START button for 2-seconds or until a beep is heard, a quick tap of the finger will not start the mill or operate controls.</li> <li>Correct any shop power supply problems causing breakers or fuses to trip and reconnect mill to power supply.</li> <li>Fully close chip guard, or replace bad switch.</li> <li>Repair for cause of short and replace 20A fuse.</li> <li>Repair for cause of short and replace 20A fuse.</li> <li>Reset switch or replace bad switch.</li> <li>Turn dial on, or replace bad switch.</li> <li>Replace capacitor.</li> <li>Replace inverter unit.</li> <li>Inspect wiring connections, plugs, and repair/replace as required (<b>Page 32</b>).</li> <li>Inspect motor and repair/replace as required (<b>Page 32</b>).</li> </ol> |
| Feed handle tapping button does not work.              | <ol style="list-style-type: none"> <li>Machine is not in "<b>Tapping Mode</b>."</li> <li>Tapping button slip ring switch is at fault (<b>Figure 37</b>).</li> <li>General electrical problem.</li> </ol>   | <ol style="list-style-type: none"> <li>Press the START and then the TAPPING button (<b>Page 19</b>).</li> <li>Replace tapping button slip ring switch.</li> <li>Inspect circuit boards, wiring connections, plugs, and repair/replace as required (<b>Page 32</b>).</li> </ol>  |
| Control panel FORWARD and REVERSE buttons do not work. | <ol style="list-style-type: none"> <li>Machine is not in "<b>Milling Mode</b>."</li> <li>General electrical problem.</li> </ol>  | <ol style="list-style-type: none"> <li>Holding for 2-seconds each or until a beep is heard, press the STOP and then the START buttons (<b>Page 19</b>).</li> <li>Inspect circuit boards, wiring connections, plugs, and repair/replace as required (<b>Page 32</b>).</li> </ol>   |

# Troubleshooting



This section covers the most common problems and corrections with this type of machine. **WARNING! DO NOT** make any adjustments until power is disconnected and moving parts have come to a complete stop!

## Milling Operation and Finish Results

| PROBLEM                            | POSSIBLE CAUSE  | CORRECTIVE ACTION  |
|------------------------------------|---|--|
| Poor surface finishes.             | <ol style="list-style-type: none"> <li>1. Feed rate too fast.</li> <li>2. Dull or bent cutter.</li> <li>3. Spindle speed incorrect.</li> <li>4. Lock lever(s) loose.</li> <li>5. Spindle is extended too far down.</li> <li>6. Gibs loose.</li> </ol> | <ol style="list-style-type: none"> <li>1. Slow feed rate.</li> <li>2. Replace or sharpen cutter.</li> <li>3. Recalculate and reset spindle RPM (<b>Page 20</b>).</li> <li>4. Tighten column and table locks when possible to maintain rigidity.</li> <li>5. Retract the spindle into the headstock completely, and lower headstock to the work area to maintain maximum rigidity.</li> <li>6. Adjust the gibs (<b>Pages 27 &amp; 28</b>).</li> </ol> |
| Vibration when running or cutting. | <ol style="list-style-type: none"> <li>1. Feed rate too high.</li> <li>2. Spindle is extended too far down.</li> <li>3. Loose table.</li> <li>4. Loose gibs.</li> </ol>   | <ol style="list-style-type: none"> <li>1. Slow feed rate or adjust RPM.</li> <li>2. Retract the spindle into the headstock completely, and lower headstock to the work area to maintain maximum rigidity.</li> <li>3. Tighten table locks.</li> <li>4. Adjust the gibs (<b>Pages 27 &amp; 28</b>).</li> </ol>  |
| Headstock hard to raise.           | <ol style="list-style-type: none"> <li>1. Headstock lock or gib is at fault.</li> <li>2. Dovetail is binding.</li> <li>3. Headstock lead screw is binding.</li> </ol>   | <ol style="list-style-type: none"> <li>1. Loosen/replace lock lever and adjust gib Adjust the gibs (<b>Page 28</b>).</li> <li>2. Clean and relubricate dovetail and ways (<b>Page 29</b>).</li> <li>3. Clean and relubricate headstock leadscrew and gears (<b>Page 29</b>).</li> </ol>  |

## Gibs and Backlash


During the life of your mill drill, you may have to adjust the gibs and the handwheels to remove any lash or looseness that is a result of normal wear. Do not overtighten the gibs or half-nuts, or premature wear will occur.

To adjust the table gibs and the handwheel backlash, do these steps:


1. DISCONNECT THE MILL FROM POWER!
2. Loosen the four lock nuts (**Figure 29**).
3. When properly adjusted, the table should move with slight resistance as felt in the handwheel. Each gib has multiple lock nuts and set screws that must also be adjusted. Make your adjustments equally and in small increments.
4. Tighten the lock nuts.
5. Remove the table end plate cap screws and the end plate (**Figure 30**).
6. Locate the X-axis lead screw half-nut (**Figure 31**), and adjust both cap screws until the handwheel has approximately 0.003" backlash as shown by the dial.
7. Repeat **Step 6** on the Y-axis leadscrew half-nut and lubricate the lead screws and gibs.



**Figure 29.** Gib screws and adjustment.



**Figure 30.** Table end plate.



**Figure 31.** Handwheel backlash adjustment.



To adjust the headstock gibs, do these steps:

1. DISCONNECT THE MILL FROM POWER!
2. Loosen the headstock lock lever (**Figure 32**).
3. Loosen or tighten the upper and lower gib screws (**Figure 32**) in an alternating manner to adjust the headstock gib.

The headstock should slide smoothly with no play or looseness. Do not overtighten the gibs or premature slide and gib wear will occur.

4. Lubricate the headstock way and gib.





Figure 32. Headstock gib adjustment.

# Service Lubrication

On an annual basis, or every six months under heavy use, we recommend that you clean and lubricate the headstock leadscrew and gears with white lithium grease and a light machine oil.

To lubricate the leadscrew and gears, do these steps:

1. DISCONNECT THE MILL FROM POWER!
2. Use the hex wrench to remove the two lower cap screws from the cabinet assembly (see **Figure 33**).
3. Hold the cabinet assembly, and remove the two upper cap screws (see **Figure 33**).
4. Carefully lift and swing the cabinet assembly out of the way from the column, and rest it aside.
5. Using mineral spirits, a toothbrush, and rags, thoroughly clean the leadscrew and gears.
6. Paint the headstock leadscrew and gear teeth with lithium grease, and oil the bearings as outlined in **Figure 33**.
7. Reinstall the cabinet assembly on the column.



**Figure 33.** Headstock leadscrew access and lubrication.

# Electrical Components




Figure 34. Motor power supply circuit board.





Figure 35. Main power switch and fuse.








Figure 36. Control panel electrical.




Figure 39. Tachometer electrical.





Figure 37. Chip guard safety switch.




Figure 38. Tapping button slip ring contact.



# Wiring Diagram (M1111)




| COLOR KEY |    |
|-----------|----|
| BLACK     | Bk |
| WHITE     | Wt |
| GREEN     | Gn |
| RED       | Rd |
| YELLOW    | Yl |
| BLUE      | Bl |
| BROWN     | Br |
| ORANGE    | Or |



# PARTS

## Column, Table, and Inverter



| REF   | PART #      | DESCRIPTION              |
|-------|-------------|--------------------------|
| 100   | XM1111100   | FLAT SPRING              |
| 101   | XPN01M      | HEX NUT M6-1             |
| 102   | XM1111102   | BALL OILER               |
| 103   | XPK37M      | KEY 4 X 4 X 16           |
| 104   | XPSB15M     | CAP SCREW M5-.8 X 20     |
| 105   | XM1111105   | UNIVERSAL LEVER          |
| 106   | XM1111106   | OIL BOTTLE               |
| 107   | XM1111107   | T-NUTS                   |
| 108   | XPR01M      | EXT RETAINING RING 10MM  |
| 112   | XPR06M      | EXT RETAINING RING 16MM  |
| 117   | XPSB01M     | CAP SCREW M6-1 X 16      |
| 118   | XPSB24M     | CAP SCREW M5-.8 X 16     |
| 119   | XPW02M      | FLAT WASHER 5MM          |
| 120   | XM1111120   | MOTOR PC BOARD/INVERTER  |
| 120-1 | XM1111120-1 | CAPACITOR 1200MFD 250VAC |
| 120-2 | XM1111120-2 | HARNESS WITH PLUGS       |
| 120-4 | XM1111120-4 | FUSE 20A 250VAC          |
| 123   | XM1111123   | POWER CORD               |
| 125   | XPRP35M     | ROLL PIN 5 X 10          |
| 127   | XPW02M      | FLAT WASHER 5MM          |
| 128   | XM1111128   | MAIN POWER SWITCH        |
| 129   | XM1111129   | COLUMN                   |
| 130   | XM1111130   | LEFT SIDE PLATE          |
| 131   | XM1111131   | RIGHT SIDE PLATE         |
| 132   | XPSB33M     | CAP SCREW M5-.8 X 12     |
| 133   | XM1111133   | LIMIT SLEEVE             |
| 134   | XM1111134   | LOWER BEARING SEAT       |
| 135   | XM1111135   | VERTICAL LEAD SCREW      |
| 136   | XM1111136   | VERTICAL LEAD NUT        |
| 137   | XM1111137   | SUPPORT                  |
| 138   | XM1111138   | UPPER BEARING SEAT       |
| 139   | XM1111139   | REAR CABINET             |
| 140   | XM1111140   | VENTED COVER             |
| 141   | XM1111141   | LARGE COVER              |
| 142   | XPSB04M     | CAP SCREW M6-1 X 10      |
| 143   | XPSB03M     | CAP SCREW M5-.8 X 8      |
| 144   | XPW04M      | FLAT WASHER 10MM         |
| 145   | XPSB14M     | CAP SCREW M8-1.25 X 20   |
| 146   | XPRP86M     | ROLL PIN 8 X 45          |
| 147   | XPSS31M     | SET SCREW M5-.8 X 8      |
| 148   | XPS17M      | PHLP HD SCR M4-.7 X 6    |
| 149   | XPB73M      | HEX BOLT M10-1.5 X 50    |
| 150   | XPRP39M     | ROLL PIN 4 X 20          |
| 151   | XPRP56M     | ROLL PIN 4 X 25          |
| 152   | XPRP73M     | ROLL PIN 4 X 30          |
| 153   | XM1111153   | RULER                    |

| REF | PART #    | DESCRIPTION                 |
|-----|-----------|-----------------------------|
| 154 | XM1111154 | SPINDLE SPANNER WRENCH      |
| 155 | XP51101   | THRUST BEARING 51101        |
| 156 | XP6001    | BALL BEARING 6001           |
| 157 | XM1111157 | ADJUSTABLE FOOT             |
| 158 | XM1111158 | BASE                        |
| 159 | XM1111159 | SADDLE                      |
| 160 | XM1111160 | WORKTABLE                   |
| 161 | XM1111161 | SPACER                      |
| 162 | XM1111162 | Y-AXIS FEED SCREW           |
| 163 | XM1111163 | X-AXIS FEED SCREW NUT       |
| 164 | XM1111164 | Y-AXIS FEED SCREW NUT       |
| 165 | XM1111165 | X-AXIS GIB                  |
| 166 | XM1111166 | Y-AXIS BEARING SEAT         |
| 167 | XM1111167 | GEAR                        |
| 168 | XM1111168 | SLEEVE                      |
| 169 | XM1111169 | Z-AXIS SHAFT                |
| 170 | XM1111170 | SUPPORT FLANGE              |
| 171 | XM1111171 | X-AXIS FEED SCREW           |
| 172 | XM1111172 | Y-AXIS GIB                  |
| 173 | XM1111173 | X-AXIS BEARING SEAT         |
| 174 | XPN09M    | HEX NUT M12-1.75            |
| 175 | XM1111175 | HANDWHEEL                   |
| 176 | XPN03M    | HEX NUT M8-1.25             |
| 177 | XM1111177 | HANDWHEEL                   |
| 178 | XM1111178 | POINTER                     |
| 179 | XM1111179 | HANDLE SLEEVE               |
| 180 | XM1111180 | INLAY RING                  |
| 181 | XM1111181 | GRADUATED DIAL              |
| 182 | XM1111182 | SHOULDER SCR M8-1.25 X 55   |
| 183 | XPSB23M   | CAP SCREW M4-.7 X 12        |
| 184 | XPSS12M   | SET SCREW M6-1 X 25         |
| 185 | XPW01M    | FLAT WASHER 8MM             |
| 186 | XPRP42M   | ROLL PIN 3 X 20             |
| 187 | XPS37M    | PHLP HD SCR M6-1 X 6        |
| 188 | XM1111188 | RIVET                       |
| 189 | XPN18M    | ACORN NUT M8-1.25           |
| 190 | XM1111190 | CHUCK KEY                   |
| 192 | XM1111192 | SEALED FLEX CONDUIT (LONG)  |
| 193 | XM1111193 | SEALED FLEX CONDUIT (SHORT) |
| 194 | XM1111194 | FUSE HOUSING ASSEMBLY       |
| 195 | XM1111195 | HEX WRENCH SET 3, 4, 5, & 6 |
| 196 | XM1111196 | DRAWBAR HEX WRENCH          |
| 197 | XPWR1214  | END WRENCH 12/14            |
| 198 | XPWR1719  | END WRENCH 17/19            |
| 199 | XPWR810   | END WRENCH 8/10             |



This diagram is an exploded view of a mechanical assembly, showing various components and their assembly sequence. The parts are numbered as follows:

- 201, 202, 203, 204, 205, 206, 207, 208, 209
- 210, 211, 212, 213, 214, 215, 216
- 217, 218, 219, 220, 221, 222, 223, 224, 225, 226, 227, 228, 228-1
- 230, 231, 232, 233, 234, 235, 236, 237, 238, 239, 240, 241, 242, 243, 244, 245, 246, 247, 248, 249
- 250, 251, 252, 253, 254, 255, 256
- 257, 258, 259, 260, 261, 262, 263, 264, 265, 266, 267, 268, 269
- 270, 271, 272, 273, 274, 275, 276, 277, 278, 279, 280, 281, 282, 283, 284, 285, 286, 287, 288, 289, 290, 291, 292, 293, 294, 295, 296, 297, 298, 299, 300, 301, 302, 303, 304, 305, 306, 307, 308, 309, 310, 311, 312, 313, 314, 315, 316, 317, 318, 319, 320, 321, 322, 323, 324, 325, 326, 327, 328, 329, 330, 331, 332, 333, 334, 335, 336, 337, 338, 339, 340, 341
- 360, 363, 365, 366, 367, 368, 369, 370, 371, 372, 373, 374, 375, 376, 377, 378

| REF   | PART #      | DESCRIPTION                |
|-------|-------------|----------------------------|
| 201   | XM1111201   | ARBOR (R-8/JT-6)           |
| 202   | XM1111202   | SPINDLE                    |
| 203   | XM1111203   | OIL SEAL                   |
| 204   | XM1111204   | TAPER ROLLER BEARING 32907 |
| 205   | XM1111205   | OIL SEAL                   |
| 206   | XPN06M      | HEX NUT M5-.8              |
| 207   | XPS79M      | PHLP HD SCR M3-.5 X 8      |
| 208   | XM1111208   | DISPLAY BRACKET            |
| 209   | XM1111209   | BLOCK AND STUD             |
| 210   | XM1111210   | SPINDLE SLEEVE             |
| 211   | XM1111211   | SLEEVE LIMIT PAD           |
| 212   | XP6006      | BALL BEARING 6006          |
| 213   | XM1111213   | THRUST WASHER              |
| 214   | XP80106     | BALL BEARING 80106         |
| 215   | XM1111215   | THRUST WASHER              |
| 216   | XM1111216   | SPANNER NUT M2-.4 X 1.5    |
| 217   | XM1111217   | SHORT LOCK SLEEVE          |
| 218   | XM1111218   | LONG LOCK SLEEVE           |
| 219   | XM1111219   | LOCK SPACER                |
| 220   | XM1111220   | HUB AND LOCK BOLT          |
| 221   | XPRP15M     | ROLL PIN 3 X 8             |
| 222   | XPS79M      | PHLP HD SCR M3-.5 X 8      |
| 223   | XM1111223   | CONTROL PANEL              |
| 224   | XPFH41M     | FLAT HD SCR M4-.7 X 16     |
| 225   | XM1111225   | INDICATOR LIGHT            |
| 226   | XM1111226   | EMERGENCY STOP SWITCH      |
| 227   | XM1111227   | TOUCH PANEL                |
| 228   | XM1111228   | CONTROL PANEL PC BOARD     |
| 228-1 | XM1111228-1 | HARNESS WITH PLUGS         |
| 229   | XM1111229   | DIGITAL SPINDLE DEPTH UNIT |
| 230   | XM1111230   | LEVER                      |
| 231   | XPFH13M     | FLAT HD SCR M3-.5 X 10     |
| 232   | XM1111232   | SPINDLE ORIENTATION SHAFT  |
| 233   | XM1111233   | HEADSTOCK                  |
| 234   | XM1111234   | SUPPORT FLANGE             |
| 235   | XPR06M      | EXT RETAINING RING 16MM    |
| 236   | XM1111236   | TORSION SPRING COVER       |
| 237   | XM1111237   | TORSION SPRING             |
| 238   | XPSB23M     | CAP SCREW M4-.7 X 12       |
| 239   | XPR12M      | EXT RETAINING RING 35MM    |
| 240   | XPR63M      | INT RETAINING RING 65MM    |
| 241   | XP6007      | BALL BEARING 6007          |
| 242   | XM1111242   | BEARING HOUSING            |
| 243   | XPSB24M     | CAP SCREW M5-.8 X 16       |
| 244   | XM1111244   | COGGED PULLEY              |
| 245   | XM1111245   | DRAWBAR 7/16-20 TPI        |
| 246   | XM1111246   | TAPER PIN 3 X 18           |
| 247   | XPSB130M    | CAP SCREW M10-1.5 X 16     |
| 248   | XPFH32M     | FLAT HD SCR M4-.7 X 6      |
| 249   | XM1111249   | DISPLAY HOUSING            |

| REF | PART #    | DESCRIPTION                |
|-----|-----------|----------------------------|
| 250 | XM1111250 | LENSE                      |
| 251 | XM1111251 | DIGITAL SPEED DISPLAY UNIT |
| 252 | XM1111252 | BELT COVER                 |
| 253 | XPSB29M   | CAP SCREW M6-1 X 40        |
| 254 | XM1111254 | SPINDLE COVER BASE         |
| 255 | XPSB17M   | CAP SCREW M4-.7 X 10       |
| 256 | XM1111256 | SPINDLE COVER              |
| 257 | XM1111257 | COGGED BELT 5M400          |
| 258 | XM1111258 | SPECIAL SCREW M6-1 X 16    |
| 259 | XPRP44M   | ROLL PIN 3 X 10            |
| 260 | XM1111260 | PINNED WASHER              |
| 261 | XM1111261 | COGGED DRIVE PULLEY        |
| 262 | XPSB02M   | CAP SCREW M6-1 X 20        |
| 263 | XPW03M    | FLAT WASHER 6MM            |
| 264 | XPN06M    | HEX NUT M5-.8              |
| 265 | XPB94M    | HEX BOLT M5-.8 X 25        |
| 266 | XM1111266 | MOTOR SUPPORT PLATE        |
| 267 | XPB23M    | KEY 5 X 5 X 25             |
| 268 | XM1111268 | MOTOR 230V                 |
| 269 | XPSB15M   | CAP SCREW M5-.8 X 20       |
| 270 | XPSB22M   | CAP SCREW M4-.7 X 35       |
| 271 | XM1111271 | GUIDE                      |
| 272 | XM1111272 | SLEEVE                     |
| 273 | XM1111273 | FRICTION DISC              |
| 274 | XM1111274 | COMPRESSION SPRING         |
| 275 | XM1111275 | VERTICAL SLIDE             |
| 276 | XM1111276 | GIB                        |
| 277 | XM1111277 | ADJUSTING SCREW            |
| 278 | XM1111278 | SHORT GEAR SHAFT           |
| 279 | XPB69M    | KEY 4 X 4 X 12             |
| 280 | XM1111280 | COMPRESSION SPRING         |
| 281 | XM1111281 | PLATE                      |
| 282 | XPFH19M   | FLAT HD SCR M4-.7 X 10     |
| 283 | XM1111283 | PIVOT HUB                  |
| 284 | XPSS03M   | SET SCREW M6-1 X 8         |
| 285 | XM1111285 | INLAY SHAFT                |
| 286 | XM1111286 | END SHAFT                  |
| 287 | XM1111287 | LEVER ASSEMBLY             |
| 288 | XM1111288 | TAPER PIN 3 X 10MM         |
| 289 | XM1111289 | RIVET                      |
| 290 | XM1111290 | POINTER PLATE              |
| 291 | XM1111291 | ADJUST SCREW               |
| 292 | XM1111292 | ANGLE GAUGE                |
| 293 | XPRP03M   | ROLL PIN 5 X 20            |
| 294 | XM1111294 | T-BOLT                     |
| 295 | XPW04M    | FLAT WASHER 10MM           |
| 296 | XPN41M    | ACORN NUT M10-1.5          |
| 297 | XPR09M    | EXT RETAINING RING 20MM    |
| 298 | XM1111298 | PINION GEAR                |
| 299 | XM1111299 | PINION FLANGE              |


| REF | PART #    | DESCRIPTION              |
|-----|-----------|--------------------------|
| 300 | XPSB16M   | CAP SCREW M4-.7 X 16     |
| 301 | XM1111301 | THRUST WASHER            |
| 302 | XM1111302 | SLIP-RING ASSEMBLY       |
| 303 | XM1111303 | WORM HOUSING             |
| 304 | XP8101    | BALL BEARING 8101        |
| 305 | XM1111305 | SUPPORT FLANGE           |
| 306 | XPSB17M   | CAP SCREW M4-.7 X 10     |
| 307 | XM1111307 | BALL OILER               |
| 308 | XM1111308 | SCREW LOCK SLEEVE 6 X 20 |
| 309 | XPSB24M   | CAP SCREW M5-.8 X 16     |
| 310 | XPSB15M   | CAP SCREW M5-.8 X 20     |
| 311 | XM1111311 | FLANGE                   |
| 312 | XM1111312 | BUTTON CONTROL ROD       |
| 313 | XM1111313 | COMPRESSION SPRING       |
| 314 | XM1111314 | HANDLE ASSEMBLY          |
| 315 | XPR80M    | EXT RETAINING RING 4MM   |
| 316 | XM1111316 | RACK HUB                 |
| 317 | XPRP37M   | ROLL PIN 3 X 14          |
| 318 | XM1111318 | SMALL MAGNETIC BLOCK     |
| 319 | XM1111319 | UNIVERSAL HANDLE         |
| 320 | XM1111320 | SPINDLE LOCK HANDKNOB    |
| 321 | XM1111321 | LOCK SHAFT               |
| 322 | XM1111322 | STEEL BALL 8MM           |
| 323 | XM1111323 | RING                     |
| 324 | XPS12M    | PHLP HD SCR M3-.5 X 6    |
| 325 | XM1111325 | LIMIT SWITCH             |
| 326 | XM1111326 | CONTACT ARM              |
| 327 | XPS12M    | PHLP HD SCR M3-.5 X 6    |
| 328 | XM1111328 | WORM SHAFT               |

| REF | PART #    | DESCRIPTION            |
|-----|-----------|------------------------|
| 329 | XM1111329 | SPACER                 |
| 330 | XM1111330 | SUPPORT FLANGE         |
| 331 | XM1111331 | WORM HANDWHEEL         |
| 332 | XPW01M    | FLAT WASHER 8MM        |
| 333 | XPNO3M    | HEX NUT M8-1.25        |
| 334 | XPNO18M   | ACORN NUT M8-1.25      |
| 335 | XPNO5M    | KEY 4 X 4 X 10         |
| 336 | XPSB33M   | CAP SCREW M5-.8 X 12   |
| 337 | XM1111337 | SUPPORT FLANGE         |
| 338 | XPNO46M   | KEY 6 X 6 X 8          |
| 339 | XM1111339 | GEAR SHAFT             |
| 340 | XM1111340 | VENT COVER             |
| 341 | XPSB17M   | CAP SCREW M4-.7 X 10   |
| 360 | XPNO1M    | HEX NUT M6-1           |
| 365 | XM1111365 | COMPRESSION SPRING     |
| 366 | XPFH56M   | PHLP HD SCR M2-.4 X 10 |
| 367 | XM1111367 | LIMIT SWITCH           |
| 368 | XM1111368 | INSULATION WASHER      |
| 369 | XM1111369 | SUPPORT PLATE          |
| 370 | XPSB18M   | CAP SCREW M4-.7 X 8    |
| 371 | XM1111371 | MAGNET                 |
| 372 | XM1111372 | BLOCK                  |
| 373 | XPS38M    | PHLP HD SCR M4-.7 X 10 |
| 374 | XM1111374 | SAFETY LENSE           |
| 375 | XM1111375 | SHAFT                  |
| 376 | XPRP15M   | ROLL PIN 3 X 8         |
| 377 | XM1111377 | COVER                  |
| 378 | XM1111378 | SPACER                 |

# Label Placement

## ! WARNING

Safety labels warn about machine hazards and how to prevent machine damage or injury. The owner of this machine **MUST** maintain the original location and readability of all labels on this machine. If any label is removed or becomes unreadable, **REPLACE** that label before allowing the machine to enter service again. Contact Woodstock International, Inc. at (360) 734-3482 or [www.shopfoxtools.com](http://www.shopfoxtools.com) to order new labels.



| REF | PART #     | DESCRIPTION               |
|-----|------------|---------------------------|
| 401 | XLABEL-08H | READ MANUAL LABEL         |
| 402 | XM1015239  | ENTANGLEMENT HAZARD LABEL |
| 403 | XLABEL-01  | SAFETY GLASSES LABEL      |
| 404 | XLABEL-14  | ELECTRICITY LABEL         |

| REF | PART #     | DESCRIPTION               |
|-----|------------|---------------------------|
| 406 | XM1111406  | DATA LABEL                |
| 407 | XM1111407  | GENERAL WARNING LABEL     |
| 408 | XLABEL-02A | UNPLUG POWER 110V LABEL   |
| 409 | XPPAINT-9  | SHOP FOX LIGHT GREY PAINT |



# Warranty

Woodstock International, Inc. warrants all **SHOP FOX®** machinery to be free of defects from workmanship and materials for a period of two years from the date of original purchase by the original owner. This warranty does not apply to defects due directly or indirectly to misuse, abuse, negligence or accidents, lack of maintenance, or reimbursement of third party expenses incurred.

Woodstock International, Inc. will repair or replace, at its expense and at its option, the **SHOP FOX®** machine or machine part which in normal use has proven to be defective, provided that the original owner returns the product prepaid to a **SHOP FOX®** factory service center with proof of their purchase of the product within two years, and provides Woodstock International, Inc. reasonable opportunity to verify the alleged defect through inspection. If it is determined there is no defect, or that the defect resulted from causes not within the scope of Woodstock International Inc.'s warranty, then the original owner must bear the cost of storing and returning the product.

This is Woodstock International, Inc.'s sole written warranty and any and all warranties that may be implied by law, including any merchantability or fitness, for any particular purpose, are hereby limited to the duration of this written warranty. We do not warrant that **SHOP FOX®** machinery complies with the provisions of any law or acts. In no event shall Woodstock International, Inc.'s liability under this warranty exceed the purchase price paid for the product, and any legal actions brought against Woodstock International, Inc. shall be tried in the State of Washington, County of Whatcom. We shall in no event be liable for death, injuries to persons or property or for incidental, contingent, special or consequential damages arising from the use of our products.

Every effort has been made to ensure that all **SHOP FOX®** machinery meets high quality and durability standards. We reserve the right to change specifications at any time because of our commitment to continuously improve the quality of our products.

# Warranty Registration

Name \_\_\_\_\_

Street \_\_\_\_\_

City \_\_\_\_\_ State \_\_\_\_\_ Zip \_\_\_\_\_

Phone # \_\_\_\_\_ Email \_\_\_\_\_ Invoice # \_\_\_\_\_

Model # \_\_\_\_\_ Serial # \_\_\_\_\_ Dealer Name \_\_\_\_\_ Purchase Date \_\_\_\_\_

*The following information is given on a voluntary basis. It will be used for marketing purposes to help us develop better products and services. Of course, all information is strictly confidential.*

1. How did you learn about us?

\_\_\_\_\_ Advertisement

\_\_\_\_\_ Friend

\_\_\_\_\_ Local Store

\_\_\_\_\_ Mail Order Catalog

\_\_\_\_\_ Website

\_\_\_\_\_ Other:

2. How long have you been a woodworker/metalworker?

\_\_\_\_\_ 0-2 Years

\_\_\_\_\_ 2-8 Years

\_\_\_\_\_ 8-20 Years

\_\_\_\_\_ 20+ Years

3. How many of your machines or tools are **Shop Fox®**?

\_\_\_\_\_ 0-2

\_\_\_\_\_ 3-5

\_\_\_\_\_ 6-9

\_\_\_\_\_ 10+

4. Do you think your machine represents a good value?

\_\_\_\_\_ Yes

\_\_\_\_\_ No

5. Would you recommend **Shop Fox®** products to a friend?

\_\_\_\_\_ Yes

\_\_\_\_\_ No

6. What is your age group?

\_\_\_\_\_ 20-29

\_\_\_\_\_ 30-39

\_\_\_\_\_ 40-49

\_\_\_\_\_ 50-59

\_\_\_\_\_ 60-69

\_\_\_\_\_ 70+

7. What is your annual household income?

\_\_\_\_\_ \$20,000-\$29,000

\_\_\_\_\_ \$30,000-\$39,000

\_\_\_\_\_ \$40,000-\$49,000

\_\_\_\_\_ \$50,000-\$59,000

\_\_\_\_\_ \$60,000-\$69,000

\_\_\_\_\_ \$70,000+

8. Which of the following magazines do you subscribe to?

\_\_\_\_\_ Cabinet Maker

\_\_\_\_\_ Popular Mechanics

\_\_\_\_\_ Today's Homeowner

\_\_\_\_\_ Family Handyman

\_\_\_\_\_ Popular Science

\_\_\_\_\_ Wood

\_\_\_\_\_ Hand Loader

\_\_\_\_\_ Popular Woodworking

\_\_\_\_\_ Wooden Boat

\_\_\_\_\_ Handy

\_\_\_\_\_ Practical Homeowner

\_\_\_\_\_ Woodshop News

\_\_\_\_\_ Home Shop Machinist

\_\_\_\_\_ Precision Shooter

\_\_\_\_\_ Woodsmith

\_\_\_\_\_ Journal of Light Cont.

\_\_\_\_\_ Projects in Metal

\_\_\_\_\_ Woodwork

\_\_\_\_\_ Live Steam

\_\_\_\_\_ RC Modeler

\_\_\_\_\_ Woodworker West

\_\_\_\_\_ Model Airplane News

\_\_\_\_\_ Rifle

\_\_\_\_\_ Woodworker's Journal

\_\_\_\_\_ Modeltec

\_\_\_\_\_ Shop Notes

\_\_\_\_\_ Other:

\_\_\_\_\_ Old House Journal

\_\_\_\_\_ Shotgun News

9. Comments: \_\_\_\_\_


\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

FOLD ALONG DOTTED LINE



Place  
Stamp  
Here



WOODSTOCK INTERNATIONAL INC.  
P.O. BOX 2309  
BELLINGHAM, WA 98227-2309



FOLD ALONG DOTTED LINE

TAPE ALONG EDGES--PLEASE DO NOT STAPLE

